





## HZ 91-330

TYP/TYPE	HZ91-330/900	HZ91-330/1350	HZ91-330/1800
A	900	1350	1800
B	1260	1710	2160
C	1760	2210	2660
D	920	1370	1820
E	1080	1530	1980
F	2400	2700	3200
G	1750	1975	2080
H	1025	1250	1475
I	263	315	367
K	2228	3185	3642
L	1750	1990	2230
$M_{min.}(kW)$	200	315	400
$M_{max.}(kW)$	400	500	600
N	1810	2210	2610
O	1050	1375	1600
P	2800	3350	3680
Q	4,478	5160	5722
R	2200	2300	2400
S	3000 ÷ 15000	3000 ÷ 15000	3000 ÷ 15000