





HZ 91-500

TYP/TYPE	HZ91-500/1350	HZ91-500/1800	HZ91-500/2400
A	1350	1800	2400
B	1720	2160	2760
C	2250	2710	3300
D	1330	1780	2380
E	1570	2020	2620
F	2800	3300	3600
G	2030	2255	2580
H	1175	1400	1700
I	960	1060	1060
K	3935	1360	4760
L	2430	2650	2980
M_{min} (kW)	400	500	600
M_{max} (kW)	600	800	1000
N	2380	2750	3280
O	1310	1540	1840
P	3340	3795	4420
Q	5965	6615	7340
R	2400	2600	2600
S	3000 ÷ 15000	3000 ÷ 15000	3000 ÷ 15000